No.	Superseded	No.	Supersedes
1-16	7-21-44		



INSTALLATION-RUDDER ATTACTION GEAR
SCALE - ½ SIZE



NOTES:
1. ATTACH JAMES END OF FRONT CROSS WIRES TO WIRE PULL BEFORE ATTACHING REAR WIRE.
2. FOR SOCKET WELDING, SEE DWG. KC-W-328
3. FOR CANTON BRAUN RUDDER WIRE DWG. KC-W-328
4. AN-302-3 & 54-S-2003 COMBINED AS 60-S-220-1 (REQ) TO BE USED AS REQ. FOR 60-S-209-1
5. 54-S-2003-3 & 54-S-2004 COMBINED AS 60-S-220-2 (REQ) TO BE USED AS REQ. FOR 60-S-209-3
6. USE 60-S-903 AS REQ. FOR 60-S-209









SEE ATTACHED BILL OF MATERIAL

NEXT ASSEMBLY	PER ASSY	PER AIRCR.	CALCUL.	DETAIL	5-1-44 DRAWN	CHECKED	5-9-44 CHECKED	APPROVED	APPROVED	UNLESS OTHERWISE SPECIFIED ±
	NO. REQUIRED		WEIGHT							SCALE: 1" = 12"
			154.80							DATE OF PRINTING

AIRCRAFT CORPORATION
EGE POINT LONG ISLAND, N. Y.

FLOAT INSTALLATION
PIPER L-4 A, J-3

60-S-908 A